

Thank you for purchasing the Ultra-Fab King Pin Tripod.
It was a wise purchase, and I'm sure it will provide you with many years of service.

Assembly instructions

Most of the assembly has been completed for you, however you will need To attach a foot pad, the connecting pin is provided.

How to Use

To use your Ultra-Fab King Pin Tripod, hold the chain in one hand, and position the tripod below the king pin of your coach. Pull up on the chain lifting the cup up over the king pin. Hook the chain link over the pin welded to the leg bracket. Turn the handle of the cup counter clockwise until the cup is snug against the king pin. Two or three additional turns are normally sufficient for stabilization.

To lock, place lock through the 2 holes in cup and lock. The neck of the lock has enough interference in the cup, that the king pin cannot be removed.

Your King pin tripod is now stable and secure.

Ultra Fab Products Inc.

19-950200

**King Pin Tripod
Aluminum**

NO.	QTY.	PART NO.	DESCRIPTION
1	1	19-001055	BRACKET-LEG
2	3	19-001050	LEG
3	3	19-001052	ARM
4	1	19-001053	BRACKET-CONNECTING
5	1	19-001056	KING PIN CUP
6	1	19-001054	CHAIN
7	1	19-001022	PAD LOCK
8	3	19-001051	FOOTPAD
9	6	19-001019	BOLT-1/2-13 X 1 1/2" HEX
10	3	19-001020	BOLT-1/2-13 X 1 1/2" HEX
11	3	19-001018	BOLT-3/8-16 X 1" TRUSS
12	12	38-020090	NUT-3/8-16 NYLOCK

