




**Installation Instructions for Hitch Protector Skid Wheel**  
**(PN #48-979020)**



**Illustration 1**

1. Refer to **Illustration 1** above.
2. Place mounting bracket on outside of receiver hitch opening.
3. Insert the receiver hitch pin to hold roller assembly in place. (The hitch pin is not included and should be a part of the hitch.)
4. Grease skid roller bearings through the zerk fittings before use.

Note: The hitch protector can be used while towing trailer.

**Parts List**

No.	Name	QTY
1	Hitch Protector Skid Wheel	1