



Thank you for purchasing the Ultra-Fab **Quick Support (PN 19-960003)**. It was a wise purchase, and we are sure it will provide you with many years of service.

How to Use

The slide out **Quick Support** is very easy to use!

Place the **Quick Support** under the slide-out, with one hand, press the white button and with the other lift the channel support up to the slide-out frame - making sure that the channel support straddles the frame member. Turn the handle clockwise until snug. Once snug give it an additional turn. **The goal is to support not lift.**

The removal of the **Quick Support** is just as easy! Turn the handle counter-clockwise, (lowers the channel support) lower it enough that you can get the stabilizer out from under the slide out. To collapse the **Quick Support**, hold the channel support while pushing the white button and lower. It is now ready for storage.

ILLUS.#	PART #	DESCRIPTION	QTY REQ
1	19-001069	TUBE-MAIN ASSEMBLY LARGE	1
2	19-001068	JACKSCREW ASSEMBLY LARGE	1
3	19-001070	HANDLE-NUT ASSEMBLY	1

