


INSTALLATION/OPERATION



APPLICATION

The Phoenix 4000 Electric Tongue Jack is a 12-volt motor-driven screw jack for use on travel trailers, boat trailers, and cargo trailers.

SPECIFICATIONS

Vertical Load – 4000 lbs. continuous over full stroke with 6000 lbs. instantaneous tongue breakaway capacity.

Travel - 18"

Power Requirement - 12V DC.

Outer Tube OD - $2^{1}/_{4}$ "

Inner Tube OD - 2"

Retracted Height - 30"

Removable Foot Pad - $5^{1}/_{2}$ " dia. (Adjustable)

Approximate Shipping Weight – 27 lbs.

INSTALLATION

- Block the wheels and support the trailer "A" frame securely.
- 2. Remove the existing jack.

NOTE: Save the original nuts, bolts, and washers that came with the jack you are replacing for installing the Phoenix 4000 Electric Tongue Jack.

- 3. Install the Electric Tongue Jack using original nuts and bolts. Depending on user's personal preference, align the motor head so that the motor housing is facing the front of the "A" frame or so that the motor housing is facing the driver side of the trailer.
- 4. The Electric Tongue Jack was designed to replace an existing manual jack. The diameter of the outer tube of your chosen jack, will need to match the existing hole size, or you will need to modify the hole diameter to fit.
- 5. Install Fuse Holder. By cutting the RED wire loop, then either crimping or soldering the connections, attach one end to the positive post of the trailer battery. The other end of the fuse holder's RED wire will be connected to the RED wire from the jack. This RED wire provides 12V power to jack.
- 6. Connect the RED positive lead to the positive terminal of the battery. Connect the BLACK ground wire to negative terminal of the battery.



WARNING

When using an extension wire, DO NOT use smaller than #10 gauge wire.

CAUTION: We do not recommend using the flip-up type footpad. Doing so requires the tongue jack to be altered which voids the warranty and can cause the failure of the jack.

OPERATION

- 1. Block trailer wheels securely.
- 2. The Phoenix 4000 Electric Tongue Jack is operated by means of the touch pad located next to the motor housing.
- 3. To extend jack, push Extend Button.
- 4. To retract jack, push Retract Button.
- 5. The GREEN light should turn on and remain on while jack is in Extend/Retract operation.
- 6. If a steady RED light comes on in Extend/Retract operation, a low voltage situation exits and the battery needs to be fully charged.
- 7. If the RED light flashes quickly for three (3)



PHOENIX 4000 ELECTRIC TONGUE JACK P/N 38-944040

seconds, a high amp situation exits and jack will turn off after three (3) seconds. The jack will reset itself in five (5) seconds and can be used again until a high amp situation occurs.

- A. The high amp draw situation can be caused by too much load. Reduce the tongue weight of the trailer.
- B. The high amp draw can also be caused by worn parts and the jack needs to be serviced and owner should call Ultra-Fab for service options.

MANUAL OPERATION

- 1. Disconnect the fuse. (unscrew and pull apart)
- 2. Remove twist plug in the access hole. (located top center of the housing cover)
- 3. Insert the supplied $\frac{9}{16}$ " socket in the access hole, over the drive hex head. Using your own socket handle, rotate the socket clockwise to retract and counter clockwise to extend.
- 4. When complete, remove socket and replace twist plug, and reassemble the fuse connection.



IMPORTANT: If you have Recalibration must be performed before resuming normal operation. Or damage could result.

CALIBRATION METHOD TO SET TRAVEL LIMITS


The jack is calibrated at the factory and is ready for use when taken out of the box. If the jack has been manually operated, serviced or if the jack is suspected to be out of calibration for whatever reason, then user should recalibrate the travel limits. To calibrate the travel limits of the jack, follow these steps:

- 1. Press and hold Extend/Retract button for three (3) seconds and GREEN light will flash three (3) times indicating both buttons are pushed.
- After three (3) seconds the WHITE light will flash indicating the jack is in calibration mode. Press Extend or Retract button so that the end of the outer tube is located on the top edge of the calibration hole (see parts list view).
- 3. Press and hold LIGHT button until WHITE light goes off indicating that the jack is now calibrated. After the white light goes off, the jack will immediately move (up or down about 3/8") to set the location sensor. The calibration hole should not be visible after the location sensor has set.
- 4. Jack is now ready to use by pushing Extend or Retract buttons.
- 5. User can also determine if the jack is out of calibration by operating the jack to Extend/Retract limit to see if the outer tube is extended beyond one of the two travel limit

indicator holes in the inner tube facing toward the tow vehicle. If the outer tube travels beyond these preset holes — **STOP** - the jack immediately.

WARNING

The jack should never be extended or retracted beyond these travel limit indicators. If these limits are exceeded, damage to the jack can occur causing the jack to fail and could result in personal injury. The jack needs to be recalibrated immediately.



MEMORY BUTTON


Remembers the height location for hooking and unhooking from tow vehicle.

While unhooking from the tow vehicle, Extend/Retract the jack to the desired location that allows the coupler to clear the hitch ball and unhook the trailer from the tow vehicle. This is the position that jack will return to while hooking back up to the tow vehicle by following these steps:

- 1. Push and hold the RED Memory Button for three (3) seconds and the GREEN light flashes three (3) times to set the memorized position of the jack at the desired height.
- 2. Once the Memory position has been set, pushing the RED Memory button will take the jack to the memorized location.
- Once the jack is traveling to the memory location and user wants to stop the jack for whatever reason, press the memory button again and the jack will stop. To resume the memory function, press the memory button and the jack will proceed to the memory location.
- 4. Otherwise, use the Extend and Retract buttons to operate the jack. The memory button should only be used to set the memory location and to travel to the memory location.




MOTOR/GEAR ASSEMBLY



#	PART#	DESCRIPTION	QTY
12	38-753006	Memory Button	1
13	38-753021	Collar	1
14	38-753017	Gear Box	1
15	38-753031	Outer Tube	1
16	38-141023	Wire LockPin	1
17	38-751101	Footpad Adjustable	1
18	38-753022	Inner Tube	1
19	38-753023	Ball Screw Set	1
20	38-753024	Clutch Assembly	1
21	38-753025	Friction Washer	1


_	PART#	DESCRIPTION	QTY
NWOHSTON	38-751167	Manual Override	1
		Socket - 9/16"	1
	38-751034	250V 30A Slow-Blow	1
		Fuse	1
	38-751035	Fuse Holder	1

#	PART#	DESCRIPTION	QTY
1	35-753001	Twist Plug	1
2	35-753002	Plastic Housing Cover	1
3	38-753011	PCB-Main	1
4	38-753012	Gear Box Cover	1
5	38-753013	Drive Gear	1
6	38-753014	Bevel Gear Assembly	1
7	38-753015	Light	1
8	38-753016	Motor	1
9	38-753003	Lens	1
10	38-753004	Motor Housing	1
11	38-753005	Keypad	1





PHOENIX 4000 WIRING DIAGRAM







TWO-YEAR LIMITED WARRANTY

ULTRA 3502/3502-7/4000/4002 & PHOENIX 4000 TONGUE JACKS

THE MANUFACTURER NAMED BELOW MAKES THE FOLLOWING WARRANTY WITH RESPECT TO THE ABOVE ULTRA-FAB PRODUCTS

- 1. This Warranty is made only to the first Purchaser (hereinafter called the "Original Purchaser") who acquires this product for their own use.
- This Warranty will be in effect for two years from the date of purchase by the Original Purchaser. It is suggested that the Original Purchaser retain a copy of the dated bill of sale as proof of the date of purchase.
- 3. This Warranty covers only specified parts which shall be free from defects in material and workmanship under normal use. This Warranty does not cover conditions unrelated to the material and workmanship of the product. Such unrelated conditions include, but are not limited to (a) faulty installation and any damage resulting from such; (b) the need for normal maintenance and any damage resulting from the failure to provide such maintenance; (c) failure to follow Manufacturer's instructions for use of this product, and (d) any accident to, or misuse of, any part of this product and any alteration by anyone other than the Manufacturer or its authorized representative.
- 4. In order to obtain the benefits of this Warranty, you should return the product which you find defective to the Manufacturer named below during the period that this Warranty is in effect. All charges incurred in delivery of the product to the Manufacturer, and in picking it up after the Warranty service has been completed, must be paid by the Original Purchaser.
- 5. Any item returned in the manner described in paragraph 4 will be examined by the Manufacturer. If it is found that the returned item was defective in material or workmanship, the Manufacturer will repair it without charge for material and labor.
- 6. Ultra-Fab will pay freight on replacement parts during the first 90 days of ownership by the Original Purchaser.
- 7. The Manufacturer does not authorize any person or company to create any Warranty obligation or liability on their behalf.
- 8. IN NO EVENT SHALL THE MANUFACTURER BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.
- ANY IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR ANY PURPOSE, IS LIMITED TO THE DURATION
 OF THIS LIMITED WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION
 MAY NOT APPLY TO YOU.
- 10. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Ultra-Fab Products, Inc.

57985 SR 19 S., Elkhart, IN 46517 Tel: (574) 294-7571 Fax: (574) 294-4980 www.ultra-fab.com

EXTENDED WARRANTY

Ultra-Fab Products offers an EXTENDED WARRANTY on this jack.
Please visit our website www.ultra-fab.com click on the WARRANTY tab
and select EXTENDED WARRANTIES.

OU WILL NEED TO WRITE DOWN	THE MODEL AND SERIAL NUMBERS
FROM THIS TONGUE JACK.	(located on the post of this jack)

Model Number:	
Serial Number: _	



Please visit our website www.ultra-fab.com ick on the WARRANTY tab and se

click on the WARRANTY tab and select REGISTER YOUR WARRANTY.

As a registered ULTRA-FAB customer, you'll be able to:

 Stay informed of new products, announcements, and special offers.
 Get faster updates and news by including your email address.